



ENGLISH

- Insert in the lock the handle with the pre-assembled spindle (1).
- Insert the right handle (2) until it rests against the door.
- Tighten the grub screw (3) well with the supplied allen key ; do not use electric or pneumatic screwdrivers.
- Tighten the grub screw (4) well with the supplied allen key until the handles are firmly attached to the door.

Disassembly

To disassemble properly the handle follow the instructions backwards, from step 4 to step 1.

N.B.: The grub screws provided have a special thread locker treatment, effective up to 4 consecutive assemblies.