



Caratteristiche tecniche  
Caractéristiques techniques  
Technische Daten  
Technical data  
Características técnicas




Istruzioni di montaggio  
Instructions de montage  
Montage-Anleitung  
Mounting-instructions  
Instrucciones de montaje



**EFFEGI BREVETTI** s.r.l.

via Buoizzi, 12 - 20090 Segrate (MI)  
tel. +39 02 26921838 - fax +39 02 26921737  
[www.effegibrevetti.it](http://www.effegibrevetti.it) - e-mail [info@effegibrevetti.it](mailto:info@effegibrevetti.it)



PEXXX410064

PEXXX450064

PEXXX600064

PEXXX620064

V = 367min  
 397max

V = 398min  
 474max

V = 475min

V = 490min

S = 388

S = 445

S = 583

S = 610

P = 134

P = 154

P = 196


P = 203

Pm = 226

Pm = 257

Pm = 332

Pm = 345




Per maniglie sporgenti considerare gli ingombri del movimento

Avec des poignées en saillie, prendre en considération l'encombrement total du mouvement

Für vorstehende Griffe bitte den Platzbedarf des Beschlages bedenken

For protruding handles pls. consider the needed space for the mechanism

Para tiradores que sobresalgan, tener considerar el espacio que ocupa el mecanismo en su movimiento



PEXXX410064

PEXXX450064

PEXXX600064

PEXXX620064

V = 367min  
397max

V = 398min  
474max

V = 475min

V = 490min

U = 367

U = 415

U = 550

U = 580

P = 134

P = 154

P = 196

P = 203

Pm = 226


Pm = 257

Pm = 332

Pm = 345


Colonna/Base - Colonne/Base -  
Hochschrank/Unterschrank - Column/base -  
Columna/Base


Il meccanismo supera una sporgenza di 40mm  
con 1mm di fuga  
Le mécanisme permet un dépassement de 40mm  
avec un jeu de 1mm  
Der Beschlag überwindet einen Vorsprung von  
40mm bei 1mm Fuge  
The mechanism overcomes a projection of 40mm  
with 1mm seam  
El mecanismo supera una ocupación de 40mm  
con una fuga de 1mm



Ripiani - Tablettes - Böden - Shelves - Baldas

I ripiani devono rientrare rispetto al filo del mobile  
per evitare la barra stabilizzatrice  
Les tablettes doivent rester en retrait en raison de  
la position de la barre stabilisatrice en position  
"porte fermée"  
Die Böden müssen in der Tiefe zurückspringen, um  
der Stabilisierungs-Stange  
auszuweichen.  
The shelves must be shorter than the cabinet-  
inner-depth in order to avoid the stabilization bar  
Las baldas deben estar por dentro del costado del  
mueble para así poder alojar la barra estabilizadora





Ingombro ante moduli affiancati


Encombrement de la porte par rapport aux éléments adjacents

Tür-Überdeckung bei Reihenkonfiguration

Door-cover with line-configuration

Comportamiento del mecanismo ante los modulos laterales

	T=18	T=19	T=20	T=22	T=24	T=26	T=28	T=30	T=32	T=35
F= 9	A= 1	A= 1	A= 1	A= 1	A= 3	A= 7	A=**	A=**	A=**	A=**
F=10	A= 1	A= 1	A= 1	A= 1	A= 3	A= 6	A= 9	A=**	A=**	A=**
F=12	A= 1	A= 1	A= 1	A= 1	A= 1	A= 4	A= 7	A=10	A=**	A=**
F=14	A= 1	A= 1	A= 1	A= 1	A= 1	A= 2	A= 5	A= 8	A=11	A=**
F=15	A= 1	A= 1	A= 1	A= 1	A= 1	A= 1	A= 4	A= 7	A=10	A=**
F=16	A= 1	A= 1	A= 1	A= 1	A= 1	A= 1	A= 3	A= 6	A= 9	A=14
F=18	A= 1	A= 1	A= 1	A= 1	A= 1	A= 1	A= 1	A= 4	A= 7	A=12
F=19	A= 1	A= 1	A= 1	A= 1	A= 1	A= 1	A= 1	A= 3	A= 6	A=11
F=20	A= 1	A= 1	A= 1	A= 1	A= 1	A= 1	A= 1	A= 2	A= 5	A=10
F=22	A= 1	A= 1	A= 1	A= 1	A= 1	A= 1	A= 1	A= 1	A= 3	A= 8
F=25	A= 1	A= 1	A= 1	A= 1	A= 1	A= 1	A= 1	A= 1	A= 1	A= 5
F=28	A= 1	A= 1	A= 1	A= 1	A= 1	A= 1	A= 1	A= 1	A= 1	A= 2
F=30	A= 1	A= 1	A= 1	A= 1	A= 1	A= 1	A= 1	A= 1	A= 1	A= 1



PEGASO  
PEXXX410064  
PEXXX450064  
PEXXX600064  
PEXXX620064


Meccanismo unico per apertura destra e sinistra.

Mécanisme unique pour ouverture à gauche ou à droite.



Ein Beschlag für Öffnung rechts und links.


One mechanism for left and right opening.

Un unico mecanismo tanto para apertura de puertas a la derecha como a la izquierda.




Foratura mobile  
Perçage sur meuble  
Bohrungen Korpus  
Drilling of furniture  
Mecanizacion del mueble




BUXP06120 

fori - trous - Bohrung - holes - taladro  
Ø 8 x 15





Foratura ante  
Perçage sur porte  
Bohrungen Türen  
Drilling of doors  
Mecanizacion de la  
puerta





7

BUXP06120 

fori - trous - Bohrung - holes - taladro

Ø 8 x 15



PEXXX410064

PEXXX450064

PEXXX600064

PEXXX620064

$$X = 242 + A$$

$$Y = 20.5 + B$$

$$X = 273 + A$$




$$Y = 20.5 + B$$

$$X = 348 + A$$

$$Y = 20.5 + B$$

$$X = 363 + A$$

$$Y = 20.5 + B$$



PEXXX410064  
+PEXVTXXX64

PEXXX450064  
+PEXVTXXX64

PEXXX600064  
+PEXVTXXX64

PEXXX620064  
+PEXVTXXX64

$X = 254 + A$   
 $Y = -8 + B$


$X = 285 + A$   
 $Y = -8 + B$

$X = 360 + A$   
 $Y = -8 + B$

$X = 375 + A$   
 $Y = -8 + B$

Premontaggi PEGASO  
Prèmontage PEGASO  
VorMontage PEGASO  
Pre-assembling PEGASO  
Premontaje del PEGASO

9






Montaggio PEGASO  
Montage PEGASO  
Montage PEGASO  
Assembling PEGASO  
Montaje del PEGASO

10

- 1. Innestare il meccanismo
- 1. Accrocher le mécanisme en place
- 1. Beschlag aufsetzen
- 1. Position mechanism
- 1. Poner el mecanismo

- 2. Fissare
- 2. Fixer
- 2. Befestigen
- 2. Fix with screws
- 2. Fijarlo


 M6 x 16



 M6 x 16

Premontaggi ante  
Prèmontage de la porte  
Vormontage Türen  
Pre-assembling doors  
Premontaje de la puerta


11




Montaggio ante  
Montaggi  
Montage Türen  
Assembling doors  
Montaje de la puerta

12


1. Agganciare l'anta
1. Accrocher la porte en place
1. Tür einhängen
1. Hang-on door
1. Enganchar la puerta




1. Agganciare l'anta
1. Accrocher la porte en place
1. Tür einhängen
1. Hang-on door
1. Enganchar la puerta



2. Avvitare
2. Visser
2. Befestigen
2. Fix screws
2. Atornillarla



2. Avvitare
2. Visser
2. Befestigen
2. Fix screws
2. Atornillarla





Regolazioni anta  
 Réglage de la porte  
 Tür-Einstellung  
 Regulations door  
 Regulación de la puerta

Regolazione verticale  
 Réglage vertical  
 Einstellung vertikal  
 Vertical regulation  
 Regulacion vertical


Regolazione laterale  
 Réglage latéral  
 Einstellung seitlich  
 Lateral regulation  
 Regulacion lateral

Regolazione frontale  
 Réglage frontal  
 Einstellung neigung  
 Frontal regulation  
 Regulacion frontal



1. Allentare le viti di fissaggio  
 1. Relâcher les vis de fixation  
 1. Befestigungsschrauben lösen  
 1. Loosen fixing screws  
 1. Aflojar los tornillos de fijación


2. Tarare altezza con il grano superiore  
 2. Régler la hauteur à l'aide de la vis supérieure  
 2. Höhe mittels oberer Madenschraube einstellen  
 2. Set height with superior screw  
 2. Regular con el tornillo superior de regulación



+ 4 mm

1. Allentare le viti di fissaggio  
 1. Relâcher les vis de fixation  
 1. Befestigungsschrauben lösen  
 1. Loosen fixing screws  
 1. Aflojar los tornillos de fijación

2. Muovere l'anta  
 2. Actionner la porte  
 2. Schrauben anziehen  
 2. Move door  
 2. Mover la puerta



1. Allentare le viti di fissaggio  
 1. Relâcher les vis de fixation  
 1. Befestigungsschrauben lösen  
 1. Loosen fixing screws  
 1. Aflojar los tornillos de fijación

2. Avvitare  
 2. Visser  
 2. Tür bewegen  
 2. Fix screws  
 2. Attornillar

